

EXIT

EXIT

4	8	12	16	20	24	28
3	7	11	15	19	23	27

WC

34	38	42	46	50
33	37	41	45	49

COFFEE

TV

TV

TV

2	6	10	14	18	22	26	30	32	36	40	44	48
1	5	9	13	17	21	25	29	31	35	39	43	47

